

## **Tip Sheet 108 Mantle Clock**

**www.bestblanks.com**

Thank you for purchasing this 5756 WALL CLOCK. By following these simple steps, you will be able to easily assemble the clock.:

- 1)** Remove the protective film from both tiles. Sublimate tiles as normal [400°F for 60-75 sec]
- 2) Slide the 6x6 tile into the wooden clock frame from the bottom.
- 3) Slide the 6x8 tile into the wooden clock frame from the bottom.
- 4) Using the two screws provided, screw the base of the clock to the clock frame. A #2 Phillips screw driver is required.

**IMPORTANT:** DO NOT continue with step 5 until the previous 4 steps are complete.

- 5) Assemble the clock movement to the 6x6 tile by putting the stem through the center hole from the backside, placing the gold flat washer over the stem from the front side and screwing the nut over the stem while holding on to the movement by hand.
- 6) Carefully put the hands on the clock stem; Hour hand first, Minute hand second. Care should be taken as to not bend the hands. This movement does not have a second hand.
- 7) Place the felt pads on the wood clock. Four pads should be placed on the base corners for use as a free standing clock. Two pads should be placed on the back lower corners for use as a wall hanging clock.