

Important! The new TECHNI-PRINT 4.0 is more flexible & reliable however be aware some adjustment in your image maybe needed in order to achieve the desired results.

If the color is too light or not as deep as desired, increase the density or darken the image on the software and/or the printer. Starting with the lightest setting. If the toner is fused so that it will not rub off with a tissue; that is the correct setting. If the color is not deep enough make further color adjustments as described above.

Heat transfer paper should always be kept in a sealed (zipper) bag, so it doesn't dry out or change its properties. It should always be fed into the printer short edge first.

TECHNI-PRINT® 4.0 Papers are designed for both oil and oil-less laser printers and copiers. They are for the heat transfer of photos and images to T-shirts, sweatshirts, mousepads, coasters, puzzles, handbags, binders, padfolios, paper, leather, magnets, wood veneer, nylon and more. Choose garments that have a tight weave. This is particularly important when transferring to sweatshirts.

PRINTING

For printing onto textiles (ie: Shirts, mouse pads, etc) Set your resolution to 200-250 DPI maximum. Printing at higher resolutions than this is a waste. Fabric can only hold approximately 200-250 DPI of resolution! You will still get good photo quality results.

1. Mirror the image.
2. Load the paper so that the image will appear on the coated side of the paper. Fan the sheets of transfer paper on all four sides to reduce static charge. Place the paper in by-pass tray (if available)
3. TECHNI-PRINT® 4.0 Paper should be fed into the copier or printer with the short dimension first (grain long).
4. Start with "Plain Paper" mode. If toner does not fuse completely, adjust to a heavier paper setting.
5. Trim away the unprinted areas of the transfer for softer hand (feel) if desired.

TRANSFERRING

Using a Commercial Heat Press (only)

1. Place the transfer sheet face down on the substrate and press: **30 seconds at 375°F using heavy pressure.** Press must snap closed firmly.
2. Peel while **still hot!** Peel Transfer IMMEDIATELY



LASER
OIL and OIL-LESS



WHITE and
LIGHT COLOR



NO HAND IRON

TEMPERATURE	375°
PRESSURE	Heavy
TIME	30 seconds

Choose a white or light colored substrate. Cotton/poly blend shirts will give you the best washability. You can also apply to 100% polyester such as mouse pads. When applying to 100% cotton shirts the image will transfer fine. However, cotton tends to fray in the wash and therefore is not recommended for a digital transfer process.

WASHING INSTRUCTIONS

Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low heat setting. Do not iron directly on the transferred area.

STORAGE AND HANDLING OF TECHNI-PRINT® 4.0 HEAT TRANSFER PAPERS

Store TECHNI-PRINT® 4.0 Papers in a cool, dry area and do not remove from carton or poly bag until you are ready to use.

IMPORTANT

We thoroughly test each of our products on various substrates using different transfer equipment. However, it is impossible for us to duplicate all variables using all substrates and transfer equipment. Therefore, it is essential that you test the paper prior to production using your equipment, methods, and substrate material. Heat presses vary in accuracy. Conduct tests to determine the best time and temperature to use with your equipment. Please keep in mind that the Seller's and Manufacturer's maximum obligation shall be to replace any paper that has proven to be defective. Neither the Seller nor the Manufacturer shall be liable for any injury, direct or consequential, arising out of the use of, or inability to use this paper.

Your One Stop Source!

www.BESTBLANKS.com
888-431-7385
954-989-1250