

PRINTING INSTRUCTIONS:


1. Print the reversed/mirrored image on the coated side of the paper.
2. Trim away the unprinted areas of the transfer.

PRE-TRANSFERRING INSTRUCTIONS:

1. Preheat iron to highest setting – do NOT use steam (empty all water).
2. Iron on a SMOOTH HARD surface; do NOT use an ironing board.
3. Place a pillowcase on the surface and iron the pillowcase removing any wrinkles.
4. Place substrate on pillowcase and iron it to remove wrinkles.

TRANSFERRING INSTRUCTIONS:

1. Place image on top of garment with image facing down (backing of paper is facing you).
2. Using 2 hands, using heavy pressure slide the iron up and down (vertically) over the entire image for 90 seconds, then repeat going from left to right (horizontally) for 90 seconds.



3. Peel the backing paper off the image after it has fully cooled.
4. For a softer feel and improved durability cover image with parchment paper and re-iron for 30 seconds.
5. Peel parchment paper off while hot and stretch garment.



*for smaller transfers one-half or less, the ironing time is reduced to ironing vertically 45 seconds and horizontally 45 seconds. If the transfer area is smaller than the iron, iron for 30 seconds with heavy pressure.

WASHING INSTRUCTIONS: Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low-heat setting. Do not iron directly on the transferred area. **IMPORTANT:** Heat presses vary in accuracy. The sellers and manufactures maximum obligation shall be to replace any paper that has proven to be defective.

Your One Stop Source!
www.BestBlanks.com
1-888-431-7385 954-989-1250